



Lautsprechersysteme

(Controller-/EQ-Einstellungen)

Modell SK-12.1 (N)

	Frequenz	Pegel	Okt.	Q
1.	3040 Hz	+ 3,0 dB	0,15	9,61
2.	4372 Hz	- 2,5 dB	0,1	14,42
3.	6520 Hz	+ 3,0 dB	0,15	9,61
4.	-	-	-	-
5.	-	-	-	-
6.	-	-	-	-

	Trennfrequenz	Art	Filtertyp	Delay
SK-12.1	150 Hz	HP	LR 24 dB	2,77 ms
SK-18.BRH	150 Hz	TP	LR 24 dB	-
dto.	43 Hz	HP	BW 12 dB	-

Die Sound Klinik • Dipl.-Phys. Manfred M. Schuster

✉ Kreienweg 4 • 26197 Huntlosen ☎ 04487 / 75 04 13 📠 04487 / 75 04 15

Ust-IdNr.: DE193357763